

# KIPOR

KIPOR POWER PRODUCTS CO., LTD.

IG1000 SHOP MANUAL

CARB and CETL Models



The Coast Distribution System  
December, 2008

# Preface

This manual covers the construction, function and servicing procedure of the KIPOR IG1000.

This manual is applicable to all models certified by the California Air Resources Board (CARB) and CETL built in December 2008 and onward. The construction of both generators is identical but CARB model fuel systems use certified materials. Procure the correct parts applicable to your model.

Careful observance of the instructions contained in this manual will result in safe and quality maintenance and repair work.

All information, illustrations, directions and specifications included in this publication are based on the latest product information available at the time of approval for printing.

KIPOR POWER CO., LTD, reserves the right to make changes without incurring any obligation whatever. No part of this publication may be reproduced without written permission.

# CONTENTS

1. SPECIFICATIONS/WIRING DIAGRAM .....	1
1.1 SPECIFICATIONS .....	1
1.2 WIRING DIAGRAM .....	3
2. SERVICE INFORMATION .....	4
2.1 THE IMPORTANCE OF PROPER SERVICING .....	4
2.2 IMPORTANT SAFETY PRECAUTIONS .....	4
2.3 SERVICE RULES .....	5
2.4 ELECTRICAL PRECAUTIONS .....	5
2.5 SERIAL NUMBER AND BARCODE .....	6
2.6 MAINTENANCE STANDARDS .....	7
2.7 TORQUE VALUES .....	8
3. TROUBLESHOOTING .....	9
3.1 GENERAL SYMPTOMS AND CAUSES .....	9
3.2 HARD STARTING .....	10
3.3 OIL LEVEL SWITCH .....	13
3.4 ENGINE STOPS RUNNING .....	13
3.5 ENGINE SPEED UNSTABLE .....	14
3.6 ENGINE SPEED TOO HIGH OR LOW .....	14
3.7 SMART THROTTLE .....	15
3.8 LOW OR NO AC OUTPUT .....	15
3.9 NO DC OUTPUT .....	16
4. MAINTENANCE .....	17
4.1 MAINTENANCE SCHEDULE .....	17
4.2 ENGINE OIL .....	18
4.3 CHECKING THE LOW OIL ALARM .....	18
4.4 AIR CLEANER .....	19
4.5 SPARK PLUG .....	20
4.6 VALVE CLEARANCE .....	21
4.7 FUEL TANK AND FILTER .....	24
4.8 FUEL PUMP AND HOSES .....	25
4.9 SPARK ARRESTOR .....	26
5. MUFFLER .....	27
6. AIR FILTER/CARBURETOR .....	28
6.1 AIR FILTER REMOVAL AND INSTALLATION .....	28
6.2 CARBURETOR REMOVAL AND INSTALLATION .....	28
6.3 STEPPING MOTOR REMOVAL AND INSTALLATION .....	29
6.4 CARBURETOR EXPLODED DRAWING .....	30
6.5 INSPECTION .....	31

7. CONTROL PANEL .....	32
7.1 REMOVAL AND INSTALLATION.....	33
7.2 INSPECTION .....	33
8. HOUSING/FUEL TANK .....	35
8.1 HOUSING DISASSEMBLY .....	35
8.2 FUEL TANK ASSEMBLY .....	36
9. RECOIL STARTER/AIR CONDUCT COVER/IGNITION COIL/AIR CONDUCT PLATE .....	37
9.1 DISASSEMBLY AND REASSEMBLY .....	37
9.2 AIR CONDUCT PLATE .....	38
9.3 RECOIL STARTER .....	39
9.4 IGNITION COIL.....	42
10. ALTERNATOR/TRIGGER .....	43
10.1 ALTERNATOR.....	43
10.2 INSPECTION .....	43
10.3 TRIGGER ADJUSTMENT .....	44
11. CYLINDER COVER/ROCKER ARM.....	45
11.1 DISASSEMBLY/REASSEMBLY .....	45
11.2 INSPECTION .....	46
12. CRANKCASE COVER/CAMSHAFT DRIVE CHAIN .....	47
12.1 DISASSEMBLY .....	47
12.2 CRANKCASE OIL TRAY ASSEMBLY AND DISASSEMBLY .....	47
12.3 CRANKSHAFT INSTALLATION .....	48
12.4 CRANKCASE COVER ASSEMBLY .....	49
12.5 INSPECTION .....	49
13. CRANKSHAFT/PISTON AND CONNECTING ROD .....	52
13.1 DISASSEMBLY .....	52
13.2 PISTON.....	53
13.3 INSPECTION .....	54

---

# 1. SPECIFICATIONS and WIRING DIAGRAM

---

## 1.1 SPECIFICATIONS

### Dimensions and weights

Model	IG1000
Overall Length in (mm)	18.1 (460)
Overall Width in (mm)	9.8 (248)
Overall Height in (mm)	15.6 (395)
Net Weight in (Kg)	30.8 (14)

### Engine

Model	KG144
Type	4-stroke,OHV, single cylinder, Gasoline engine
Displacement cu in. (cc)	3.3 (53.5)
Maximum horsepower/rpm	1.3/5500
Compression ratio	8.5:1
Cooling system	Forced air-cooled
Ignition system	T.C.I
Ignition timing	29°B.T.D.C
Spark plug	UR5
Carburetor	Float type, Horizontal, butterfly valve type
Air cleaner	Semi-dry type
Governor	Electronic control
Lubrication system	Forced splash
Oil capacity qt (L)	.19 (0.22)
Starting system	Recoil starter
Stopping system	Primary circuit ground
Fuel	Automotive unleaded gasoline 87 octane


### Alternator

Model	KD10
Generator type	Multi pole rotation
Generator structure	Self-ventilation drip-proof alternator
Excitation	Self-excitation (Magnet type)
Voltage regulation system	Plush width modulation
Phase	Three phase
Rotating direction	Clockwise (Viewed from the generator)
Frequency regulation	AC-DC-AC conversion

## Performance

Model	IG1000
Maximum output AC	1.0KVA
Rated output AC	0.9KVA
Rated output DC	100W
Rated frequency	60HZ
Rated voltage AC	120V
Rated voltage DC	12V
Rated current AC	7.5A
Rated current DC	8.3A
Power factor	1.0
Voltage variation rate	Momentary 10%max. Average 1.5%max. Average time 3 sec. max.
Voltage stability	±1%
Frequency variation rate	Momentary 1%max. Average 1%max. Average time 1 sec. max.
Frequency stability	±0.1%
Insulation resistance	10MΩ min.
AC circuit protector	8.8 A
DC circuit protector	10 A
Fuel tank capacity-gal (L)	.69 (2.6)
Operating hours	4
Noise level NL-FL @ 23' (7 m)	60-65 dB

## 1.2 WIRING DIAGRAM




---

## 2. SERVICE INFORMATION

---

### 2.1 The importance of proper servicing

Proper servicing is essential to the safety of the operator and the reliability of the generator. Any error or oversight made by the technician while servicing can easily result in faulty operation and/or damage to the equipment or injury to the operator.



Improper servicing can cause an unsafe condition that can lead to serious injury or death. Follow the procedures and precautions in this shop manual carefully.

Some of the most important precautions are stated below.

### 2.2 Important safety precautions

Be sure you have a clear understanding of all basic shop safety practices and that you are wearing appropriate clothing and safety equipment. When performing maintenance or repairs, be especially careful of the following:

- Read the instructions before you begin, and be sure you have the tools and skills required to perform the tasks safely.
- Be sure that the engine is off before you begin any maintenance or repairs. This will reduce the possibility of several hazards:
  - Carbon monoxide poisoning from engine exhaust.
  - Burns from hot parts.
  - Injury from moving parts.
- Do not run the engine unless the instructions tell you to do so. Keep your hands and clothing away from rotating parts.
- To reduce the possibility of fire or explosion, exercise extreme caution when working around gasoline. Use only a nonflammable solvent, not gasoline, to clean parts. Keep cigarettes, sparks and flames away from all fuel-related parts.



### **2.3 Service rules**

- Use genuine KIPOR or KIPOR-recommended parts and lubricants or their equivalents. Parts that do not meet Kipor's design specifications may damage the engine.
- Use the special tools designed for the product.
- Always install new gaskets, O-rings, etc. when reassembling components.
- Clean parts in cleaning solvent upon disassembly. Lubricate any sliding surfaces before reassembly. After reassembly, check all parts for proper installation and operation.
- Many screws used in this machine are self-tapping. Be aware that cross-threading or over tightening these screws will strip the threads and ruin the hole.
- Use only metric tools when servicing this engine. Metric bolts, nuts and screws are not interchangeable with non metric fasteners. The use of incorrect tools and fasteners will damage the engine.


### **2.4 Electrical precautions**

- Hold the connector body to disconnect the connector. Do not disconnect by pulling the wire harness. To disconnect the locking connector, be sure to unlock first, and then disconnect.
- Check the connector terminals for bend, excessive extrusion, missing terminals, or other abnormalities before connecting the connector.
- To connect, insert the connector as far as it goes. If the connector is a locking type, be sure that it is locked securely.
- Check the connector cover for breakage and check whether the connector female terminal is not opened excessively. Then, connect the connector securely. Check the connector terminal for rust. Remove the rust using an emery paper or equivalent material before connecting the connector.
- Set the harness clips in the specified places of the frame securely, and secure the wire harnesses.
- Clamp the cables securely.
- Clamp the wire harnesses securely so that they do not interfere with the rotating parts, moving parts and hot parts.
- Route and connect the wire harnesses properly. Be sure that the harnesses are not slack, twisted or pulled overly taut.
- Route the wire harnesses properly so that they do not contact sharp edges and corners and the end of the bolts and screws on the body.

- If a wire harness must contact the end of the bolts or screws or sharp edges and corners, protect the contact part of the harness with a loom or by winding with electrical insulating tape. If the wire harness has a grommet, set the grommet securely.
- Take care not to pinch the wire harnesses during installation of a part. If a wire harness has damaged insulation, repair by winding with electrical insulating tape.
- When using an electrical tester like a volt/ohm meter or clamp on meter, read the manufacturer's operating instructions carefully before operating the tester. Be sure that the tester battery is fully charged and the meter is functioning properly

## 2.5 Serial number and bar code

The generator serial number identifies your particular unit and is important when ordering parts and accessories. The bar code is used by your dealer and Coast Distribution for warranty administration. It identifies the date of manufacture. In this example, 060313 indicates the generator was manufactured on June 6, 2006.



The generator serial number is stamped on the engine block to the right of the oil dipstick. The bar code label is placed on the bottom of the generator. It is additionally found on the inside cover of the operator's manual and on the carton.

## 2.6 Maintenance standards

Part	Item		Standard(mm)	Service limit
Engine	Maximum speed without load		5500±100 rpm	—
Cylinder	Sleeve I.D.		1.712-1.714 in	1.716 in
			43.500-43.520 mm	43.595 mm
Piston	Skirt O.D		1.711-1.712 in	1.707 in
			43.460-43.480 mm	43.350 mm
	Pin bore I.D.		0.3937-0.3940 in	0.3955 in
			10.002-10.008 mm	10.050 mm
Piston pin	O.D		0.3934-0.3937 in	0.3920 in
			9.994-10.000 mm	9.950 mm
Piston ring	1st ring	Height	0.030-0.031 in	0.028 in
			0.77-0.79 mm	070 mm
		Ring side clearance	0.0008-0.0024 in	0.0059 in
			0.02-0.06 mm	0.15 mm
		Ring end clearance	0.0039-0.0098 in	0.0314
			0.10-0.25 mm	0.80 mm
	Width	0.063-0.071 in	0.055 in	
		1.60-1.80 mm	1.40 mm	
	2nd ring	Height	0.038-0.039 in	0.0354 in
			0.97-0.99 mm	0.90 mm
		Ring side clearance	0.0008-0.0024 in	0.0059 in
			0.02-0.06 mm	0.15 mm
		Ring end clearance	0.0039-0.0098 in	0.0314
			0.10-0.25 mm	0.80 mm
	Width	0.071-0.078 in	0.063 in	
		1.80-2.00 mm	1.60 mm	
	Oil ring	Height	0.053-0.058 in	0.049 in
			1.35-1.48 mm	1.25mm
		Ring side clearance	0.0008-0.0067 in	0.0090 in
			0.02-0.17 mm	0.23 mm
Ring end clearance		0.0079-0.1180 in	0.0354 in	
		0.20-0.30 mm	0.90 mm	
Width	0.3942-0.3946 in	0.3965 in		
	2.00-2.40 mm	1.80 mm		
Connecting rod	Small end I.D		0.3942-0.3946 in	0.3965 in
			10.012-10.024 mm	10.070 mm
	Big end I.D		0.5911-0.5915 in	0.5937 in
			15.015-15.025 mm	15.080 mm
Crankshaft	Crank pin O.D.		0.5896-0.5899 in	0.5866 in
			14.975-14.985 mm	14.900 mm
Valves	Valve clearance	Intake	0.0031-0.0039 in	---
			0.08-0.10 mm	---
		Exhaust	0.0039-0.0059 in	---
			0.10-0.15	---
	Stem O.D.	Intake	0.156-0.157 in	0.1535 in

		Exhaust	3.965—3.980 mm	3.900 mm
			0.1557-0.1562 in	0.1540 in
	Guide I.D.	IN/EX	3.955—3.970 mm	3.900 mm
			0.1575-0.1579 in	0.2598 in
Valve spring	Free length	IN/EX	4.000—4.012 mm	4.060 mm
			0.925 in	0.866 in
Cam wheel	Cam height		23.5 mm	22 mm
			1.101-1.103 in	1.062 in
Camshaft	O.D		27.97-28.03 mm	26.97 mm
			0.1963-0.1967 in	0.1949 in
	Camshaft bearing I.D.		4.988-4.996 mm	4.950 mm
			0.1976-0.1988 in	0.2008
Rocker arm	I.D.(Rocker arm)		5.02-5.05 mm	5.10 mm
			0.1575-0.1579 in	0.2598 in
	O.D.(Rocker arm shaft)		4.000-4.012 mm	4.050 mm
			0.1574-0.1579 in	0.1590 in
	I.D.(Rocker arm shaft bearing)		3.988-3.996 mm	3.950 mm
			0.1574-0.1579 in	0.1594 in
Spark plug	Gap		4.000-4.012 mm	4.050 mm
			0.024-0.028 in	—
Ignition coil	Resistance	Primary side	0.6—0.7 mm	—
		Second side	0.8—1.3 Ω	—
Pulse coil (Trigger)	Air gap		15 —21 kΩ	—
			0.020-0.0295 in	—
	Resistance		0.5-0.75 mm	—
			80~130Ω	—
<b>Part</b>	<b>Item</b>	<b>Type</b>	<b>Standard (Ω)</b>	
Ignition winding	Resistance	Green-Yellow/Green	0.50-0.70	
Outer charging winding	Resistance	Blue--Blue	0.16-0.20	
Sub winding	Resistance	White—White	0.25-0.35	
Main winding	Resistance	Black—Black	2.0-3.0	

## 2.7 Torque values

Item	Specification	Tightening torque	
		Ft lb.	N·m
Connection rod bolt	M5X0.8X25	5.9-7.4	8-10
Spark plug	M10X1.0X13		11-13
Flywheel nut	M10X1.25		48-52
Standard torque	M5 Bolt, nut	4.4-6.0	6-8
	M6 Bolt, nut	5.9-7.4	8-10

Note: Use standard torque values for fasteners that are not listed in this table.


### 3. Troubleshooting

This troubleshooting section contains troubleshooting trees organized by common groups of symptoms. Some testing information is contained in these sections. The following chapters of this manual focus on individual components and sub assemblies which will give you the assembly and reassembly procedures along with detailed specifications and testing procedures.

#### 3.1 General symptoms and possible causes

Engine does not start or hard starting	Fuel filter clogged	Clean
	Fuel tank tube clogged	Clean
	Fuel switch clogged	Clean
	Carburetor faulty	Readjust and clean
	Ignition coil faulty	Inspect and replace
	Spark plug faulty	Inspect and replace
	Trigger faulty or trigger clearance faulty	Inspect and replace
	Spark plug cap looses	Fix it securely
	Low oil alarm faulty	Inspect and replace
	Ignitor faulty	Inspect and replace
	Ignition winding faulty	Inspect and replace
	Throttle opening fault	Set in fully close or half close position
Engine speed does not stabilize, too high or too low	Carburetor faulty	Adjust and/or disassemble and clean
	Throttle control motor (stepping motor) faulty	Inspect and replace
	Inverter unit faulty	Inspect and replace
	Valve clearance misadjusted	Readjust


### 3.2 Hard starting



#### ■ Cylinder compression check

1. Remove the spark plug cap and spark plug.
2. Install a compression gauge in the spark plug hole. Pull the recoil starter rope several times with force and measure the cylinder compression.

Cylinder compression	80 psi/0.55Mpa
----------------------	----------------




### C. Ignition system


- Fill in oil to the demanded level.
- Use the genuine spark plug A7RTC.
- Spark plug inspection
  1. Disassemble spark plug
  2. Install spark plug onto spark plug cap.
  3. Set the oil switch to the “ON” position. Ground the negative (—) electrode (i.e. threaded part) of the spark plug against the shroud and pull the recoil starter rope to check the spark plug. Normally you should see the spark jump the electrode gap when the plug is firing.



- Don't pull the recoil starter while touching the high tension wire with wet hands. High voltage generates, which is very dangerous.
- Fire may be caused if fuel spilled around the spark plug, so make sure that you test after draining off fuel completely.
- Fuel inside cylinder will be burnt if the spark plug is near the hole, so please turn off the engine first. Pull the recoil starter several times to release the unburn gas in the cylinder.




### 3.2 Hard Starting Continued







### 3.3 Engine oil level is low, but engine does not stop. (Defective oil switch)




### 3.4 Engine stops running (Throttle is at the correct position)




**3.5 Engine speed can't increase or unstable (choke is at the correct position)**




**3.6 Engine speed too high or too low**




**3.7 Smart system doesn't work with zero load or engine speed doesn't increase with Smart system on and load connected.**



**3.8 No or low AC output**



### 3.9 No DC output



## 4. Maintenance

### 4.1 Maintenance schedule

Regular service period		Each use	First month or 20 Hrs.	Every 3 months or 50Hrs.	Every 6 months or 100 Hrs.	Every year or 300 Hrs.
Item perform at every indicated month or operating hour interval, whichever comes first						
Engine Oil	Check	●				
	Replace		●		●	
Air filter	Check	●				
	Clean			●*		
Spark plug	Clean-Adjust				●	
Spark catcher	Clean-Adjust				●	
Valve clearance	Check-Adjust					●**
Fuel tank and filter	Clean					●**
Fuel line	Check	Every 2 year (Replace if necessary)				

Note:

\* Service more frequently when operating in dusty areas.


\*\* Service by KIPOR authorized service center.


### 4.2 Engine oil

#### ■ Checking for the oil level

Stop the engine and check the oil level, be sure to put the engine on a flat and level surface when checking.

1. Loosen the maintenance cover screw and remove the cover.
2. Remove the oil filler cap and check the oil level.





3. If the oil level is low, add to the edge of the oil filler port.


■ **Replace the engine oil**

1. Remove the oil dipstick and oil drain bolt, drain out dirty oil.
2. Reinstall the oil drain bolt tightly.
3. Fill with fresh oil of the proper viscosity (see operator's manual).
4. Check the oil level.
5. Tighten the oil dipstick.


■ Drain the used oil while the engine is warm. Warm oil drains quickly and completely. Avoid burns from hot oil.

**4.3 Checking the low oil alarm**

1. Disconnect oil alarm connector when the engine is still running, connect the two plugs, be sure that oil alarm lights and engine stops.



2. Stop engine, disconnect oil alarm connector, check the connector conduction, no conduct is normal.



3. Drain out the oil inside engine and check the conduction, conduct is normal.

#### 4.4 Air cleaner


##### Inspection/Cleaning:

- 1) Loosen the cover screw and remove the maintenance cover.
- 2) Disengage the locking tab by pushing it, and remove the air cleaner cover.
- 3) Remove the element from the air cleaner case.
- 4) Clean the element in warm soapy water, rinse and allow to dry thoroughly and allow to dry.
- 5) Dip the element in clean engine oil and squeeze out all the excess oil.
- 6) Install the air cleaner element in the air cleaner case.



Clean the air cleaner rubber and the air cleaner case if necessary. Be sure that the air cleaner cover seals are set securely.

7) Install the air cleaner cover. Be sure that the air cleaner cover seals are set securely.

8) Install the maintenance cover securely.



Wash clean    Airdry after wring out    Immerse oil    Squeeze out oil




**Caution**

- A dirty air cleaner will restrict air flow to the carburetor, reducing engine performance. If the engine is operated in dusty areas, clean the air cleaner more often than specified in the Maintenance Schedule.
- Never run the engine with no element or a damaged element. Engine damage will result.

**4.5 Spark plug**

**Inspection/Cleaning:**


- 1) Remove the spark plug cap and remove the spark plug.
- 2) Remove carbon or other deposits with a plug cleaner or stiff wire brush. Check the sealing washer for damage.



- 3) Measure the plug resistance; replace the spark plug if the measure is not accord with the asked value.


Spark plug resistance	3~9K $\Omega$
-----------------------	---------------





4) Measure the plug gap with a wire-type feeler gauge. Adjust by bending the side electrode if the measure is not accord with the asked valve.

Spark plug clearance	.024-.028 in. (0.6~0.7mm)
Standard spark plug	A7RTC



5). Install the plug finger tight to seat the washer, and then tighten with a plug wrench.  
Torque valve is 8.-~9.6 ft lbs, 11~13 N.m

#### 4.6 Valve clearance


### Caution

- Valve clearance inspection and adjustment must be performed with the engine cold.


#### Inspection/Adjustment:

- 1) Remove the following parts:
  - Front cover, control panel
  - Rear cover
  - Right/left side covers
  - Fuel tank
  - Inverter unit, engine bed
  - Recoil starter, fan cover
  - Inlet/Exhaust side baffle

2) Remove the four tighten bolts and disassemble the cylinder cover. Don't remove the cylinder cover with excessive force as it may deform. Replace the cylinder cover if it is deformed.



3) Remove the spark plug; screw the dial indicator in the spark plug hole. Rotate the rotor in a clockwise movement and set the piston at top dead center.



### **Caution**


- Make sure both the intake and exhaust valves are closed.

4) Insert a feeler gauge between the rocker arm and the valve and measure the valve clearance.


Valve clearance	Intake	.0031-.0039 in (0.08-0.10mm)
	Exhaust	.0039-.0059 in (0.10-0.15) mm

5) If adjustment is necessary, proceed as follows.

- a. Loosen the adjusting screw lock nut and adjust the valve clearance by turning the adjusting screw in or out.
- b. Secure the adjusting screw with a socket wrench and tighten the lock nut to the specified torque.
- c. After tightening the lock nut, check the valve clearance again.



6) Clean the liquid gasket of the cylinder block and cylinder head cover. Apply liquid gasket (Three Bond 1207B or equivalent) to the cylinder block installation surface as shown.



7) Install all parts in the reverse order of removal.


#### 4.7 Fuel tank/Fuel filter

### **Caution**

■ Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel. Keep heat, sparks, and flame away. Wipe up spills immediately.

#### **Cleaning:**

- 1) Drain the fuel from the tank and carburetor, and then remove the following parts.
  - Rear cover
  - Front cover and control panel
  - Right/Left side cover
- 2) Disconnect the fuel tube from the fuel tank, and remove the fuel filter.
- 3) Remove the clogged foreign material from the fuel filter, and check the fuel filter for damage. Replace the fuel filter if necessary.
- 4) Remove the fuel tank and clean it with cleaning solvent and allow the fuel tank to dry thoroughly.
- 5) After cleaning, install the fuel tank and set the fuel filter in the tank. Connect the fuel tube.
- 6) Install the removed parts in the reverse order of removal.
- 7) Fill the fuel tank with gasoline and check the fuel tube for gasoline leakage.



#### 4.8 Fuel pump and hoses

##### **Caution**

■ Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel. Keep heat, sparks, and flame away. Wipe up spills immediately.

1) Drain the fuel from the tank and carburetor, and then remove the following parts.

—Rear cover

—Front cover and control panel

—Right/Left side cover

2) Make sure the negative pressure tube is firmly connected to the port on the engine block. See page 37.

3) Check the fuel tube for deterioration, cracks and gasoline leakage. If there is any abnormality in the fuel tube, replace the tube.


4) Check the diaphragm tube for deterioration, crack and oil leakage. If there is any abnormality in the diaphragm tube, replace the tube.

5) Check to see whether water or foreign material has been accumulated in the fuel pump.

If there is water or foreign material accumulated in the pump, replace the fuel pump.

6) Check the fuel switch and fuel duct, blow away the foreign matter with high pressure gas with oil switch turned on.

7) After assembly, check for gasoline leakage from each part.




#### 4.9 Spark arrestor

##### **Caution**

■ Make sure the muffler has cooled completely before attempting any maintenance on this part.

- (1) Remove the rear cover
- (2) Disassemble the arrestor from muffler
- (3) Remove the carbon from the spark arrestor steel mesh with a stiff wire brush. Check for damage and replace it if necessary.
- (4) Install the removed parts in the reverse order of removal.




---

## 5. Muffler

---

### Caution

- Muffler removal/installation must be performed with the engine cold.
- **Disassembly/Reassembly**



---


## 6. Air filter/Carburetor

---


### Caution

- Loosen the drain oil bolt and drain out fuel before disassembly.
- Keep heat, flame and sparks away.

### 6.1 Air filter removal and installation




### 6.2 Carburetor removal and installation






### 6.3 Stepping motor removal and installtion



## 6.4 Carburetor exploded drawing

**Note: With the exception of changing the main jet for altitude compensation, no adjustments to this carburetor are permitted under EPA and CARB guidelines. No repair parts will be furnished.**




## 6.5 Inspection

### ● Float height

Place the carburetor as the picture shows, measure the float height between float and carburetor block.

Height	0.0047 in (12mm)
--------	------------------

Replace the carburetor if the float height is not the right size.




### ● Stepping motor

Measure the resistance of stepping motor lead-out wire.

Standard resistance	Between 1 and 3: 45~55Ω
	Between 2 and 4: 45~55Ω

Replace the stepping motor if the resistance exceeds the above range.




---

## 7. Control panel

---

### 7.1 Removal/Installation



## 7.2 Inspection

### a. Control panel

#### ● AC receptacle

Check the electrode contact disk inside receptacle; if it is burnt or discolored, replace for it.

#### ● DC receptacle

After checking the fuse, connect both terminals of the receptacle with a jumper wire to short. There must be continuity between the lead wire terminals with the circuit protector ON. Replace the DC receptacle if there is no continuity.


#### ● Smart switch

There should be continuity with the switch ON, and no continuity with the switch OFF.


#### ● Ignition Module

Pull off the 10P receptacle from the module, measure the resistance by connecting one testing pen with the metal outer case of engine, and the other testing pen with the 10P connector.

Color	Circuit unit	Standard resistance
Blue	Primary coil of the ignition coil	0.8-1.3Ω
Orange	Oil level alarm	There should be no continuity with correct oil level
Yellow	Trigger coil	80-130Ω
Yellow/Green	Ground wire	Continuity
Green	Igniter unit power coil winding	0.5-0.7Ω
Red	Engine switch	There should be no continuity with the switch ON, continuity with the switch OFF



● Engine switch




Check the continuity of connector, there should be continuity when the micro switch is depressed.

● Rectifier

Measure the on or off (positive pressure fall) of rectifier with control potentiometer  $\rightarrow (+ \sim)$ , the measurement should accord with the standard as shown in the chart.

Positive Negative	1	2	3	4
1		OFF	OFF	OFF
2	ON		OFF	OFF
3	ON	ON		ON
4	ON	OFF	OFF	


(1) Negative pin (-)      (2) AC pin (~)




(4) AC pin (~)      (3) Positive pin (+)

## 8. Housing / Fuel tank

### 8.1 Housing disassembly and reassembly




#### ● Left housing case



## 8.2 Fuel tank assembly

### Caution

- Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel. Keep heat, sparks, and flame away. Wipe up spills immediately. Loosen the drain screw to drain the carburetor thoroughly before removal.






---

## 9. Recoil starter/ Air conduct cover/ Ignition coil/ Air conduct plate


---

### 9.1 Disassembly/Reassembly




## 9.2 Air conduct plate


### Disassembly/ Reassembly




### 9.3 Disassembly and reassembly of recoil starter




(1) Set the spring into the starter reel, and hang the spring outer hook inside the reel groove.




(2) Smear lubrication grease on the starter outer shell claw, install the starter reel. Revolve the reel anticlockwise to hang the spring inner hook on the starter outer shell claw.




(3) Make a "8" knot at one end of the rope, pass the other end through the reel hole. Wind the reel anticlockwise 6 turns to fix the reel.



(4) Pull rope through from starter outer shell hole completely; pass it through the handle and make a figure eight knot, then turn off handle cover. Loosen the reel to release tension on the spring taking care not to allow the reel to pop out.



(5) Install the revolving axis, revolving axis parts and friction spring, fix it with bolts.




(6) Pull the starter for several times, and check the revolving axis.

## 9.4 Ignition Coil


- Attach the two leads of tester to the primary coil plug of ignition coil, and measure the primary resistance of the ignition coil.

Primary resistance	0.8—1.3Ω
--------------------	----------



- Attach one lead of the tester to each terminal of primary coil plugs of ignition coil and the other lead to the spark plug cap, then measure the secondary resistance of the ignition coil.


Secondary resistance	15—21kΩ
----------------------	---------



## 10. Alternator/Trigger

### 10.1 Alternator

#### Disassembly/Reassembly



### 10.2 Inspection

#### (1) Ignition winding

Measure the resistance between the green terminal and yellow/green terminal.

Resistance	0.50-0.70Ω
------------	------------

#### (2) Outer charging winding

Measure the resistance between the two blue terminals.

Resistance	0.12-0.15Ω
------------	------------

#### (3) Sub winding

Measure the resistance between the two sub winding terminals.

Resistance	White-white	0.25~0.35Ω
------------	-------------	------------

#### (4) Main winding


Measure the resistance among the terminals of the main winding.

Resistance	Black-black-black	2.0~3.0Ω
------------	-------------------	----------

### (5) Trigger

Attach the two test leads to the trigger and measure the resistance.


Trigger resistance	80-130 $\Omega$
--------------------	-----------------



### 10.3 Trigger adjustment

Adjust the clearance between trigger and the projection part of rotor.

Trigger clearance	0.0197-0.0275 in (0.50-0.75 mm)
-------------------	---------------------------------



Insert a feeler gauge between the trigger and the projection part of the rotor; loosen the trigger fixed plate bolt to adjust the clearance slightly. Never move the plastic part of trigger, to avoid it separates from the fixed plate and damages the trigger.




---

## 11. Cylinder cover/ Rocker arm

---


### 11.1 Disassembly/ Reassembly



## 11.2 Inspection


### ● Rocker arm outer diameter

Standard in (mm)	Service limit in (mm)
0.1570-0.1573 (3.988-3.996)	0.1555 (3.950)




### ● Rocker arm inner diameter of inlet/exhaust valve

Standard in (mm)	Service limit in (mm)
0.1575-0.1579 (4.000-4.012)	0.2598 (4.050)



### ● Inner diameter of rocker arm bearing

Standard in (mm)	Service limit in (mm)
0.1575-0.1579 4.000-4.012	0.2598 in 4.050




---


## 12. Crankcase cover/ Camshaft drive chain

---

### 12.1 Disassembly



### 12.2 Crankcase oil tray disassembly and reassembly




1. Clean any remaining gasket material from the cylinder block and crankcase oil tray.

2. Apply a 0.040~0.059 in (1~1.5 mm) layer of liquid gasket material [1207B or equivalent] evenly on the sealing face of the crankcase oil tray.
3. Reassemble the crankcase cover in the reverse order of disassembly.


### **Caution**

Make sure to reassemble the crankcase oil tray three minutes after applying the gasket material.



### **12.3 Crankshaft reinstallation**

1. Revolve the crankshaft slowly, placing the timing mark pointing up.
2. Install the valve tappet, move the tappet aside and then reassemble the camshaft. Note that the timing mark on the camshaft and driving gear should be oriented downward and aligned with the timing mark on the timing gear.




## 12.4 Crankcase cover assembly

1. Remove any remaining gasket material on the cylinder block and crankcase cover.
2. Apply a 0.040~0.059 in (1~1.5 mm) layer of liquid gasket material [1207B or equivalent] evenly on the cylinder block sealing face.
3. Reassemble the crankcase cover in the reverse order of disassembly.

### Caution

Install the crankcase cover on the cylinder block 3 minutes after applying the gasket material.

4. Screw on the crankcase cover bolts slowly and tighten to the prescribed torque.




## 12.5 Inspection

### ● Inspection of the oil alarm


- (1) Place the oil alarm in the position shown below. There should be no continuity between the oil alarm output wire and copper ground wire.
- (2) Turn the oil alarm 180° and check again; there should be continuity.
- (3) Immerse the oil alarm completely in oil; check the float- there should be no continuity.

**Caution:** Wait two minutes after immersing the alarm in oil before measuring.




● **Cam height**

Standard in (mm)	Service limit in (mm)
1.101-1.103 (27.97-28.03)	1.062 (26.97)




● **Cam inner diameter**

Standard in (mm)	Service limit in (mm)
0.1976-0.1988 (5.02-5.05)	0.2008 (5.10)




● **Camshaft outer diameter, tappet shaft outer diameter**

Standard in (mm)	Service limit in (mm)
0.1963-0.1967 (4.988-4.996)	0.1949 (4.950)




●Valve tappet inner diameter

Standard in (mm)	Service limit in (mm)
0.1968-0.1975 (5.000~5.018)	0.1988 (5.050)




## 13. Crankshaft/ Piston

### 13.1 Disassembly/Reassembly





## 13.2 Piston




### Assembly of piston ring

#### Caution

- Set the manufacture label up.
- Pay careful attention not to mix the location of the 1<sup>st</sup> ring and 2<sup>nd</sup> ring.
- Check the piston ring for flexibility after installation.
- Stagger each piston ring opening 120° apart.


- There may be two different kinds of piston rings for the same model generator. They can be distinguished by different manufacture labels. Don't intermix piston rings of different manufacture on the piston.



### 13.3 Inspection


- Free length of valve spring

Standard in (mm)	Service limit in (mm)
0.925 (23.5)	0.866 (22)




● **Valve stem outer diameter**

	Standard in (mm)	Service limit in (mm)
Intake valve	0.156-0.157 (3.965-3.980)	0.1535 (3.900)
Exhaust valve	0.1557-0.1562 (3.955-3.970)	0.1535 (3.900)



● **Valve guide pipe inner diameter**

	Standard in (mm)	Service limit in (mm)
Intake/Exhaust valve	0.1575-0.1579 (4.000-4.012)	0.2598 (4.060)




● **Clearance between valve stem and valve guide pipe**

	Standard in (mm)	Service limit in (mm)
Intake valve	0.0008-0.0018 (0.020-0.047)	.0039 (0.10)
Exhaust valve	0.0012-0.0022 0.030-0.057	.0047 (0.12)


● **Cylinder inner diameter**

Standard in (mm)	Service limit in (mm)
1.712-1.714 (43.500-43.520)	1.716 (43.595)



● **Piston skirt outer diameter**

Standard in (mm)	Service limit in (mm)
1.711-1.712 (43.460-43.480)	1.707 (43.350)




● **Clearance between piston and cylinder**

Standard in (mm)	Service limit in (mm)
0.0008-0.0024 (0.02-0.06)	.0047 (0.120)

● **Piston skirt outer diameter**

Standard(mm)	Service limit(mm)
57.960-57.980	57.850




● **Clearance between piston and cylinder**

Standard in (mm)	Service limit in (mm)
0.0078-0.0165 (0.020-0.042)	0.0047 (0.120)

● **Side clearance of piston ring**


Standard in (mm)	Service limit in mm
0.0008-0.0024 (0.02-0.06)	0.0059 (0.15)



● **Piston ring end clearance**


Locate the piston ring into cylinder with piston top, and measure the piston end clearance.

Standard in (mm)	Service limit in (mm)
0.0059-0.0098 (0.15-0.25)	0.0394 (1.0)




● **Piston ring height**

	Standard in (mm)	Service limit in (mm)
The 1 <sup>st</sup> ring	0.0030-0.031 (0.77-0.79)	0.028 (0.70)
The 2 <sup>nd</sup> ring	0.038-0.039 (0.97-0.99)	0.0354 (0.90)




● **Piston pin outer diameter**

Standard in (mm)	Service limit in (mm)
0.3934-0.3937 (9.994-10.000)	0.3920 9.950



● **Piston pin bore inner diameter**

Standard in (mm)	Service limit in (mm)
0.3937-0.3940 (10.002-10.008)	0.3955 (10.050)




● **Clearance between piston pin and piston pin hole**

Standard in (mm)	Service limit in (mm)
0.00008-0.00055 (0.002-0.014)	0.00314 (0.080)


● **Connecting rod small end inner diameter**

Standard in (mm)	Service limit in (mm)
0.3942-0.3946 (10.012-10.024)	0.3965 (10.070)




● **Connecting rod big end inner diameter**

Standard in (mm)	Service limit in (mm)
0.5911-0.5915 (15.015-15.025)	0.5937 (15.080)




● **Crankshaft neck outer diameter**

Standard in (mm)	Service limit in (mm)
0.5896-0.5899 (14.975-14.985)	0.5866 (14.900)



● **Connecting rod big end side clearance**

Standard in (mm)	Service limit in (mm)
.0039-.0236 (0.1-0.6)	0.0315 (0.8)







● **Oil film clearance of connection rod big end**

- (1) Wipe all oil from the surface of the crankshaft neck.
- (2) Set the plastic wire feeler at the crankshaft neck and install the connecting rod. Tighten the bolt to the prescribed torque being careful not to rotate the crankshaft. The tightening torque is 5.9-7.4 ft lb. (8-10 N.m).
- (3) Disassemble the connecting rod and measure the plastic wire feeler thickness.
- (4) Replace the connecting rod if the clearance exceeds the service limit.


Standard in (mm)	Service limit in (mm)
0.0012-0.0019 0.030-0.050	0.0039 0.10

Plasticinsulated wire clearance gauge




●Camshaft bearing inner diameter, tappet shaft bearing inner diameter (cylinder block)

Standard in mm )	Service limit in (mm)
0.1976~0.1988 (5.02~5.05)	0.2008 (5.10)



●Camshaft bearing inner diameter, tappet shaft bearing inner diameter (gear case cover)


Standard in mm )	Service limit in (mm)
0.1976~0.1988 (5.02~5.05)	0.2008 (5.10)



● **Bearing vibration**


Clean the bearing and dry it. check the clearance between crankshaft journal and connecting rod big end by rotating the bearing by hand. Replace the bearing if there is abnormal noise or vibration.

Clearance between crankshaft journal and connecting rod big end



Crankshaft direction

Crankshaft direction



Surrounding direction

Surrounding direction

Clearance between crankshaft journal and connecting rod big end