# 64 300/107 ED





## **MOUNTING INTERFACE**



## CONFIGURATIONS (see Hydraulic symbols table)

- Configuration "SA": used when control of the flow exiting from the actuator on line A is desired.
- Configuration "SB": used when control of the flow exiting from the actuator on line B is desired.
- Configuration "D": independently controls the flow exiting from the two chambers of the actuator.
- Configuration "RD": independently controls the flow entering the two chambers of the actuator.
- All the configurations have a built-in check valve that allows reverse free flow (cracking pressure of 0,5 bar).

Maximum operating pressure Check valve cracking pressure	bar	320 0,5
Maximum flow rate in the controlled lines Maximum flow rate in the free lines	l/min	80 100
Ambient temperature range	°C	-20 / +50
Fluid temperature range	°C	-20 / +80
Fluid viscosity range	cSt	10 ÷ 400
Fluid contamination degree	According to ISO 4406:1999 class 20/18/15	
Recommended viscosity	cSt	25
Mass:	kg	3,1

#### HYDRAULIC SYMBOLS



ERS4M FLOW RESTRICTOR VALVE SERIES 40

MODULAR VERSION ISO 4401-05 (CETOP 05)

p max 320 bar

**Q** max (see table of performances)

# **OPERATING PRINCIPLE**



- This is a flow restrictor valve with built in check valve for reverse free flow, made as a modular version with mounting surface according to the ISO 4401 (CETOP RP 12H) standards.
- It can be assembled quickly under all ISO 4401-05 (CETOP 05) modular valves without use of pipes, using suitable tie-rods or bolts, thus forming compact modular groups.
- It is normally supplied with SICBLOC adjustment knobs with micrometric indication and automatic locking. To operate it, push and rotate at the same time.

64 300/107 ED



## **1 - IDENTIFICATION CODE**



#### **3 - HYDRAULIC FLUIDS**

Use mineral oil-based hydraulic fluids HL or HM type, according to ISO 6743-4. For these fluids, use NBR seals. For fluids HFDR type (phosphate esters) use FPM seals (code V). For the use of other kinds of fluid such as HFA, HFB, HFC, please consult our technical department. Using fluids at temperatures higher than 80 °C causes a faster degradation of the fluid and of the seals characteristics. The fluid must be preserved in its physical and chemical characteristics.

## 4 - OVERALL AND MOUNTING DIMENSIONS





# DUPLOMATIC OLEODINAMICA SpA

20025 LEGNANO (MI) - P.le Bozzi, 1 / Via Edison Tel. 0331/472111 - Fax 0331/548328